230.00 mm

85.00 mm

EN Register your product guarantee today!
See page 15 for info.

繁體中文 請立即進行產品註冊或妥善保管您的產品保固卡，以啟動產品保固，詳情請見第 15 頁

ghd glide+ & glide+ max

Professional hot brush

important safety and user instructions, manufacturer's guarantee and how to register your product

重要安全使用說明·製造商產品註冊與保固資訊，以及產品保固卡使用指南

contents

EN English 3-8
Validate your guarantee 15
TC 繁體中文 9-13
啟動產品保固註冊 15

important safety instructions

To reduce the risk of burns, electrocution, fire, or injury to persons, read and follow these safety instructions before using your ghd hot brush.

This ghd hot brush is for use only as a hairstyling aid, and only with products specifically designed for use with a heated hairstyling aid such as a ghd heat mat.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure they do not play with the appliance.

BURN HAZARD: Keep appliance out of reach from children, particularly during use and during cool down after use.

When the appliance is connected to a power supply never leave it unattended.

The ghd hot brush is not suitable for use with synthetic hair. It is possible that colour may permanently transfer onto the hot brush if used on dyed hair.

warning: keep away from water

Do not use this device in a bathtub, shower, or water filled reservoir.



1. **When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.**
2. **For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30mA is advisable in the electric circuit supplying the bathroom. Ask your installer, or a qualified electrician, for advice.**
3. **Do not reach for the for the appliance if it has fallen into water.**
4. **Do not spray or apply wet styling aids directly onto the ghd glide+ or ghd glide+ max.**

warning: electricity

As with most electrical appliances, electrical parts are electrically live even when the switch is off.

To reduce the risk of electrocution:

Never operate this appliance if it is not working properly, or if it has a damaged power cord or plug. If the power cord or plug is damaged, it must be replaced by Jemella Ltd.

1. Only use with 220–240V, 50-60 Hz power supply.
2. The appliance should never be left unattended when plugged in.
3. Keep the power cord away from heated surfaces. Do not wrap the power cord around the appliance. Do not hang the ghd hot brush by the power cord.
4. Always unplug the ghd hot brush immediately after using.

EN

5. Do not use an extension power cord with this appliance.
6. Do not use a voltage inverter or generator with this appliance.
7. Your ghd product is a class II electrical appliance and should not be connected to an earth connection.

warning: hot surfaces

The ghd hot brush heater plate is hot for effective styling.


To reduce the risk of burns:


1. NEVER touch the heated plate of the hot brush.
2. Avoid holding or touching the hot brush beyond the raised finger guard.
3. When not styling always lay the ghd hot brush on a flat heat-resistant surface such as a ghd hot brush heat mat.
4. When styling is complete, always switch off the ghd hot brush and unplug it from the power supply.
5. Wait for the ghd hot brush to cool before storing.
6. When the ghd hot brush has cooled, fold the power cord in the same way as it was first delivered in its packaging. Do not wind it around your hand or the body of the ghd hot brush as this can lead to early failure of the power cord.
7. Always place the appliance with the stand, if any, on a heat-resistant, stable flat surface.

Your ghd glide+ is not only attractive to you, but also to your children. Please ensure you always store your ghd hot brush out of reach of children, particularly during use, especially when cooling.

operation

Ensure that hair is completely dry before using the ghd glide+.





1. Heater plate
2. On/Off Switch and indicator light
3. Power cord
4. Ioniser

1. Plug your ghd hot brush into the power supply. The switch surround will flash white for less than 1 second and beep to indicate that it is now connected to mains electricity. The appliance is now in standby mode.
2. To turn on the ghd hot brush, press and hold the ON/OFF button for at least 1 second. The ghd hot brush will play a short start-up tune and a light will pulse to indicate that the hot brush is heating up.
   IMPORTANT: the ghd hot brush heats up quickly, so don't touch the hot heater bristles! Once the ghd hot brush has reached operating temperature, it will bleep and the light will remain illuminated to indicate that it is ready to use
3. When you have finished your styling session, press and hold the ON/OFF button for more than 2 seconds to turn the appliance off. A shut down tune will play to indicate the appliance has been turned off. Once turned off, it is best practice to unplug the appliance from the mains electricity and allow it to cool in a safe place. For safe cooling place the appliance on a ghd heat resistant mat and allow to cool.

WARNING: while the appliance is cooling down do not touch the heated bristles or allow children or those with reduced physical, sensory or mental capabilities, or lack of experience and knowledge to touch the appliance whilst it is cooling.

the ghd glide+ has the following safety features:

1. **Sleep mode:** if the ghd hot brush has been left on and has not been used for 60 minutes, a safety feature will automatically turn the hot brush off. The hot brush will play the sleep mode tune, the plate will start to cool and the light will slowly pulse till the plate reaches a safe temperature.
   a. a. To restart the appliance while it is in sleep mode, simply turn it on by pressing and holding down the ON/OFF button for more than 1 second.
   b. Note that although the ghd hot brush is turned off, it is still connected to the mains and will consume 0.3W. Please unplug from mains electricity at the earliest opportunity.
2. **Fail safe:** in the unlikely event of a control system error, for safety the heaters will turn off, the ghd hot brush will emit bleeps and the light will flash red every five seconds. If this occurs un-plug and re-plug at the power supply and re-start. If the unit does not re-start or the problem persists, contact ghd Customer Service for advice

user maintenance instructions

Cleaning your ghd glide+ and glide + Max

1. Unplug the ghd hot brush from the mains power supply.
2. Always allow the ghd hot brush to cool before attempting to clean it.
3. Never immerse the appliance in water.
4. Remove all hair from in between the bristles after every usage. Wipe clean any build-up of styling products with a damp cloth or soft brush (do not scrub) from both bristles and heater plate.
5. Do not use an abrasive cleaning fluid to clean, as damage will occur.

Storage

1. Always allow the ghd hot brush to cool down before storing away.
2. When the ghd appliance has cooled down, fold the power cord in the same way as it was first delivered in its packaging. Do not wrap the supply cord around the ghd appliance as this can strain the cord and cause premature supply cord failure.

EN

failure to operate

If your product stops working and the red fault light flashes, please follow the procedure below:

1. Switch off the unit
2. Unplug the unit from the plug socket
3. Wait for 5 seconds and then plug the unit back into the wall
4. Switch the unit back on

If this occurs repeatedly, please contact your local ghd service centre.

For UK plugs, please ensure that the fitted fuse is intact and functioning; if it is not, replace it with an identically rated British Standard Fuse.

If in doubt or for further advice, please visit the help section of ghdhair.com or contact an approved ghd stockist or contact ghd Customer Service for further advice.

manufacturer's guarantee

All ghd electrical products are individually tested before leaving the factory. However, in the unlikely event of the product proving defective due to faulty workmanship or materials, then, at its sole discretion, ghd will replace the product at no charge with an identical or equivalent product within two years from the original date of purchase for end consumer for personal use, or one year for professional users. A replacement product assumes the remaining guarantee of the original product or 180 days, whichever provides longer coverage for you. When a product is exchanged, any replacement item becomes your property and the replaced item becomes property of ghd.

To claim under this guarantee please visit 'ghdhair.com/returns' and follow the on-screen instructions to complete your return. Please ensure that you include a proof of purchase with any returned product. Therefore please ensure you keep your proof of purchase in a safe place.

This guarantee only applies to genuine ghd products purchased through ghd-approved stockists, and does not cover products repaired or serviced by anyone other than ghd personnel or ghd representatives. Note that this guarantee may be invalidated where serial numbers or identification have been erased, damaged or modified. This does not affect your statutory rights.

*Neither Jemella Group Limited nor its subsidiaries provides replacement parts for any of its electrical units. If you do not have access to the internet please return your ghd electrical product to the closest ghd address as printed in this leaflet or on the packaging, together with your proof of purchase. For customers in Australia and New Zealand, please phone your closest ghd office on the number printed in this leafle

Australia Only

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

recycling and disposal

Your ghd electrical product is classified as 'electrical or electronic equipment' and **must not be disposed of with other household or commercial waste at the end of its working life.** When you have no further use for your ghd product, please dispose of it according to your local authority's recycling procedure. For more information contact your local authority.

UK/EU Only

Your ghd electrical product should be disposed of in accordance with the WEEE directive (Waste Electrical and Electronic Equipment 2002/96/EC), which ensures that products are recycled using the best available methods and practices to minimise any potential damage to the environment. For more information, contact your local authority or the retailer from whom you purchased this product.

product compliance

This ghd hot brush is compliant with EN 60335-2-23 and carries the CE mark. Other approvals include the USA, Australia/New Zealand and South Africa.

ghd UK Jemella Ltd

ghd UK: 01924 423400

Jemella Ltd
ghd Republic of Ireland: +44 1924 423 400

ghd Returns
Phase 1
Caverswall House
Sherwood Business Park
Annesley
Nottinghamshire
NG15 0DJ

Jemella Australia pty Ltd

ghd Australia: 1300 443 424
ghd Australia PO Box 15516, City East, Queensland 4002, Australia

ghd South Africa (Proprietary) Ltd

ghd South Africa: 086 010 9366
ghd South Africa PO Box 818, Gillitts, 3603, South Africa

Jemella New Zealand Ltd

ghd New Zealand: 0800 880 209
ghd New Zealand Private Bag 211030, Laurence Stevens Drive, Auckland 2154, New Zealand

ghdhair.com

ghd and ghd are registered trade marks of Jemella Group Limited.

© Jemella Group Limited 2026

Designed in Cambridge, UK. Made in China.

Model number:

- B1D001 - 220-240V ~ 50-60Hz 48W
- B1E001 - 220-240V ~ 50-60Hz 62W

重要安全使用守則

為避免錯誤操作而導致燙傷、觸電、火警及其它個人傷害，使用本產品前請認真閱讀及遵照以下安全說明。

本產品僅只適用於頭髮造型使用，並且只適用於搭配專為造型工具特別設計的耐熱產品，如ghd 專用隔熱墊一起使用。

本產品不適合兒童及肢體、感官或精神上有殘疾者、或缺乏經驗和知識的對象獨自使用，除非在專人指導或監督，且對使用者安全承擔責任的情況下方能使用。

請監督兒童，確保不會把本產品當作玩具。本產品

在缺乏監督的情況下，不得由兒童進行清潔及維護。

燒傷危險：請將本產品放在兒童接觸不到的地方，特別是在使用過程中和使用後的冷卻過程中。

在無人看管的情況下，請將本產品的插頭拔除。切勿連接電源。

本產品不適用於人造假髮。若用於染色髮，染料可能會經由高溫附著於本產品上。

警告：請遠離水源

不要在浴室、浴缸、洗臉盆或任何可能接觸到水的地方使用本產品。



1. 當電器於浴室中使用時，使用後請務必拔除電源插頭。即使已關閉電源，任何可能接觸到水的地方也會產生危險。

2. 為提供額外保護，建議安裝額定漏電電流不超過 30mA 的漏電斷路器（RCD）。請務必遵循當地相關法規，並諮詢您的安裝技術人員或合格電工以獲得專業建議。

3. 萬一產品不小心掉入水中時，請勿再觸碰或伸手撈取。

4. 請勿將任何造型品或護髮產品直接噴灑或塗抹在本產品上。

警告：小心觸電

如同大多數電器產品，即使電源開關已關閉，部份零件仍為處於待機通電狀態。

為降低觸電風險，請遵守以下事項：

如電源線或插頭有損壞，或產品不正常運行時，請立即停止使用。並於保固期內，請聯絡ghd查詢 保固服務。請勿自行修理或更換。

1. 請依照產品標示規格使用電源。
2. 無人看管時，應拔掉插頭。
3. 請勿將電源線放置於任何有熱度的表面。請勿將電源線纏繞於本產品上或用電源線懸掛本產品。
4. 每次使用後，請立即拔除電源插頭。
5. 請勿將本產品與電源延長線一起使用。
6. 請勿將本產品與電壓轉換器或電源變壓器一起使用。
7. 本產品為II類電器，不需接地使用。



警告：小心高溫表面

為有效達到造型效果，使用過程中本產品會產生高溫。

為防止燙傷或灼傷，請務必遵守以下安全事項：


1. 切勿直接觸碰加熱板。(梳齒)。
2. 凸起線以上靠近加熱板，溫度較高，請避免手指觸碰。
3. 當中途停止操作時或產品使用完畢後，請務必將本產品放在平坦且耐熱的表面上，例如ghd 專用隔熱墊。
4. 每次造型結束後，請務必關閉開關並拔掉插頭。
5. 使用完畢後，請靜置本產品讓其完全冷卻再進行收納。
6. 待本產品冷卻後，請依原包裝方法收納電源線。請切勿將電源線纏繞於手把上或機身上，這將可能造成電源線提早損壞。
7. 當中途停止操作時，或產品使用完畢後，請務必將本產品放在平坦且耐熱的表面上，例如ghd 專用隔熱墊。


中文

我們相信本產品不僅會引起你的興趣，同時也會引起小孩的好奇心。請務必將本產品放置於兒童接觸不到之空間，尤其是在使用時，特別是在冷卻過程中。

操作方式:

使用本產品前，請確保頭髮已經完全乾燥。





① 加熱板(梳齒)
② 開關和指示燈
③ 電源線
④ 負離子釋出孔

1. 將本產品的插頭插入電源插座。機身指示燈將會於1秒內快速閃亮並發出嗶聲，表示已連接電源，此時本產品已處於待機模式。
2. 長按電源開關1秒以上即可啟動預熱，本產品將會發出很短的啟動聲響，接著電源指示燈會閃爍，這表示本產品正在加熱。

重要提示：本產品在預熱的過程中，請千萬注意不要觸摸發熱面板及上面的梳齒！一旦預熱完成，會發出1聲“嗶”聲，同時電源指示燈將保持在亮燈模式，此時即可開始使用。

3. 造型完成後，長按「開/關」按鈕超過2秒即可關閉產品。產品將發出“關機提示音”，提示已關閉。關閉電源後請立即拔掉插頭，並妥善放置等待冷卻。為確保安全，請在冷卻時，請使用產品內建之底座並放置於隔熱墊上靜待冷卻。

警告：產品冷卻期間，請勿觸摸發熱面板及上面的梳齒，也請勿讓兒童、肢體、感官或精神能力較弱或缺乏經驗和知識的人士在產品冷卻期間觸摸本產品。

ghd glide+具有下列安全功能：

1. **睡眠模式：**本產品在啟動狀態下若超過60分鐘未使用，本產品會發出聲響並自動關閉開始進入睡眠模式，接著產品會開始進行冷卻，同時電源指示燈會慢速閃動。
   - **a.** 若進入睡眠模式後欲重新啟動本產品，只要將開關按鈕長按一秒以上即可重新開啟。
   - **b.** 請注意，即使本產品開關已關閉，由於仍然連接電源，功率消耗為 0.3W。為確保安全，請儘快拔掉電源插頭，並待冷卻後妥善收納。
2. **故障保護：**若不幸遇到控制系統失靈，基於安全考量，發熱器會自動關閉，會發出急促的“嗶”聲，同時電源指示燈會以紅光的方式每五秒持續閃動一次。此時可以先關機再重新啟動電源。若無法重新啟動電源或狀況持續發生無法改善，請洽ghd客戶服務部尋求協助。

產品維護說明

ghd glide+ & ghd glide+Max清潔須知

1. 清潔前，務必關閉電源及拔掉插頭。
2. 清潔前，請確保本產品已經完全冷卻。
3. 切勿將產品浸入水中清潔。
4. 每次使用後，請清除梳齒間的毛髮。用濕布或軟刷（切勿用力擦洗）擦去梳齒和加熱板上殘留的造型產品。
5. 切勿使用具腐蝕性的清潔劑進行清潔，或使用尖銳或粗糙材質擦拭本產品，以免造成損壞。

存放須知

1. 使用完畢後，須待本產品完全冷卻後再存放。
2. 待冷卻後，請按原包裝方法摺疊收納電源線。請勿將電源線纏繞於手把或機身上，以防止過度拉扯電源線所導致的提早損壞。

操作故障

由於本產品為精密儀器，若在使用時電流量落差太大時，產品會即刻進入故障保護模式以保護產品避免受損。因此，若本產品未能正常運作，請確認電源開關是否開啟，電力是否正常供應。若產品無法正常操作，電源紅色指示燈不斷閃動時，請按照以下流程操作：

1. 關機
2. 拔下插頭
3. 等待5秒後再重新將插頭連接插座
4. 開機

若有其它疑問，請前往www.ghdhair.com網站或聯絡ghd尋求協助。

注意事項: 本產品內部零件不可由使用者自行維修或更換。

若電源線損壞時，必須由製造商、其服務處或具有相關資格的人員加以更換以避免危險。

產品保固

所有ghd產品在出廠之前都經過嚴格品質檢驗。自購買日起2年內，產品若有任何生產過程或原料所導致的瑕疵問題，在經過判斷認可下，ghd將提供保固，免費替換相同或等價之產品。替換產品的保固期將延續原產品的保固期或180天（以較長的週期為準）。當產品被替換後，替換產品所有權將歸於您而被替換產品所有權將歸於ghd所有。

保固期內若需尋求保固服務，請洽詢ghd。聯絡電話：+852-2274 5422。請務必於購買產品後妥善保管發票及保固卡以及電源線上面黏貼的雷射標籤，並於提出保固申請時提供完整的資料。(建議發票及保固卡可拍照留存)

請注意：若產品曾由非 ghd 原廠專業人員或非授權代表進行維修或服務，或產品電源線上的雷射標籤與條碼被剪掉、擦除、損毀或修改，則本保固將失效。但不影響您依法享有的法定權益。

Jemella集團不會為其任何電器產品提供零件更換服務。若有其它疑問，請前往www.ghdhair.com網站或聯絡ghd尋求協助。

中文

回收與處理

本產品為“電器及電子產品”，當不再使用需廢棄產品時，必須與家庭廢棄物分開處理。當產品不再使用時，請依照您當地的法規來妥善處理您的ghd產品。更多資訊，請與當地環保機構瞭解詳情。

Ghd Hong Kong

電話: 852-2274 5422
電郵: infohk@ghdhair.com

ghdhair.com

ghd 與 ghd 皆為 Jemella Group Limited 的註冊商標。

© Jemella Group Limited 2026.

於英國劍橋設計，中國生產製造。

型號：

- B1D001 - 220-240V ~ 50-60Hz 48W
- B1E001 - 220-240V ~ 50-60Hz 62W

EN validate your guarantee

For peace of mind styling with your new ghd product, register your guarantee today for:

- Verification of the authenticity of your ghd product
- Replacement should your ghd product fail within the guarantee period*
- Exclusive offers and deals before anyone else
- The latest news and trends first

Visit ghdhair.com/register or use your QR reader on your smartphone to validate.

This does not affect your statutory rights.
* conditions apply, see safety instructions.

中文 啟動保固生效

為了讓您安心地使用本產品，請您在收到貨後執行以下動作

- 確認所購買的產品為ghd授權通路所提供的真貨。
- 確認保卡上資料的完整性，並蓋銷售地點店章及填寫購買日期：西元年月日並妥善管。務必妥善保管。以獲得保固權益*。

* 請務必詳讀重要安全使用守則之注意事項。

051125 99500000774